

PERMANENT WAY
NOTES

CHAIRS (9)

STANDARD RAILWAY EQUIP. &
RE/PW BS95R CHAIRS
IN USE ON W. REGION.

These notes are intended for the guidance and assistance of staff engaged upon permanent way work. They do NOT in any way modify, supplement or amend the instructions laid down in E.D.I., standard drawings, circulars etc., which should be referred to in all cases.

AS I (S) WT. 46 LB.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

seating depth $1\frac{3}{4}$ "

SRE 4A.

AS I J (S) WT. 53 LB.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

seating depth $1\frac{3}{4}$ "

SRE 5A.

L I (S) WT. 48 LB.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 6.

M I (S) WT. 43 LB.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 47.

CC (S) Available for flangeways: $1\frac{3}{4}$ ", 2", 2 1/4" & 2 1/2"

WT. 70 LB. ($1\frac{3}{4}$ " FC) Add 1 lb per $\frac{1}{4}$ " extra FC.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 38.

LICC (S) Available for flangeways: $1\frac{3}{4}$ ", 2", 2 1/4" & 2 1/2"

WT. 78 LB. ($1\frac{3}{4}$ " FC) Add 1 lb per $\frac{1}{4}$ " extra FC.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 36A.

CCL OR R (S) WT. 75 LB.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 38. DRAWN L.

LICCL OR R (S) WT. 83 LB.

Height of boss above chair base $1\frac{1}{2}$ "

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 38. DRAWN L.

CSI & CSIS (S) Used on concrete sleepers & with steel keys only. WT. 41 LB.

NB. CSI chair for use with chair bolt * CSIS chair for use with SC chair screw

Plain base

Seating depth $1\frac{3}{4}$ "

SRE 47A.

SIN & SIO (S) WT. 34 LB.

NB. SIN. Drawn. SIO Dimensions the same except rail inclined away from jaw. (A) = $9\frac{1}{8}$ "

Plain base

SRE 47A.

RE/PW S20A (CSIS) RE054 (CSI)
NB. CSI & CSIS are RE/PW chairs the remainder being REA pattern & must be so noted when ordering. Chairs marked (S) available with seating depth increased by $\frac{1}{16}$ " increments to $3\frac{3}{4}$ " (S24) & by $\frac{1}{12}$ " increments to $3\frac{1}{4}$ " (T18)
RE/PW baseplate screws & ferrules fit all REA chairs including these with thickened seatings.